REVISED STARTING SERIAL # 100310019

PARTS LIST MANUAL ELECTRIC POWER TROWELS



SKU#	MODEL#	SIZE	RPM	MOTOR OPTION
84600	T244B-1.5B	24"	130	
C85400	T244BRS-1.5B	24"	65	
80400	T304B-1.5B	30"	30" 130 DAI DOD 4 5UD 4 DU COUZ 445/00	BALDOR 1.5HP 1-PH 60HZ 115/230V
C85100	T304BRS-1.5B	30"	65	BALDOR 1.5HP 1-PH 60HZ 115/230V
80800	T364B-1.5B	36"	130	
C85200	T364BRS-1.5B	36"	65	
81300	T364B-2L	36"	130	LEECON 2UD 4 DU COUZ 445/220V
C86200	T364BRS-2L	36"	65	LEESON 2HP 1-PH 60HZ 115/230V



READ AND UNDERSTAND THE OPERATORS INSTRUCTION MANUAL THOROUGHLY BEFORE ATTEMPTING TO OPERATE THIS EQUIPMENT. Death or serious injury could occur if this machine is used improperly.



SAFETY MESSAGES



The safety instructions are proceeded by a graphic alert message of DANGER, WARNING, or CAUTION.



Indicates an imminent hazard which, if not avoided, will result in death or serious injury.



Indicates an imminent hazard which, if not avoided, can result in death or serious injury.



Indicates hazards which, if not avoided, could result in serious injury and or damage to the equipment.

GASOLINE "

Powered Equipment







 Do not operate gasoline powered equipment without adequate ventilation. Carbon monoxide is an invisible, odorless gas that can kill.

ELECTRICAL — Powered Equipment





<u>ELECTRICAL HAZARD</u> - Be sure equipment is properly grounded.
 Failure to comply could kill or result in serious injury.



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

GENERAL INSTRUCTIONS-





- You must read and understand the operators instruction manual and all other manuals associated with this machine. For your safety and the safety of others around you, it is extremely important to fully understand how to operate this machine in the way it was intended. Different model machines or older/newer versions of the same model may have different parts and controls that you need to understand. If instructions are not readable or available DO NOT USE this machine and contact the factory for a replacement Manual.
- You must be able to physically handle the bulk weight and power of this machine. If not properly controlled this machine can cause death or serious injury.
- Do not operate this machine in an impaired mental state. You must be able to exercise good judgement and reactions to maintain a safe working environment.
- This is a "one person" machine which means only one operator can
 be operating the machine at any one time. For the safety of others,
 maintain a safe operating distance to other personnel. Your work
 area should be defined and appropriately marked so bystanders and
 coworkers do not stand or walk near this machine and end up seriously
 injured by flying debris or exposing them to harmful noise or dust.
- This equipment is for Commercial use. Although this is a "one person" machine your work team should understand how to shut this machine off and guickly get medical help if an accident strikes the operator.
- Keep all guards in place during operation. The guards are to provide protection from inadvertent contact with dangerous moving parts, pinch points, or hot surfaces.
- Wear appropriate Personal Protective Equipment (PPE) including safety glasses, safety boots, work gloves, respiratory protection, hearing protection, and head protection. Do not wear loose clothing that can get tangled in moving parts. Failure to do so could result

- in dismemberment or death. Wear an approved respirator when removing hazardous materials or when grinding/cutting dry materials. Some dust particles such as concrete dust can contain silicate particles which can cause silicosis (a very serious lung disease). Contact NIOSH or OSHA for further details. When wet grinding/cutting, avoid contact with the concrete/asphalt slurry which can cause serious skin irritations.
- You must maintain this machine per the maintenance schedule in the
 operator manual. Remember before adjusting, servicing, or fueling this
 machine, disconnect the source of power to the machine by disconnecting the spark plug (Gas models), or by unplugging the electrical
 power cord (electric models) or air hose (Pneumatic models) AT THE
 MACHINE so you can assure yourself it remains unplugged while you
 are working on it. Do not modify this machine. Use only genuine EDCO
 parts and accessories. Repairs and service should be performed by
 approved EDCO dealers or authorized technicians.
- You should look carefully around the area before you begin work so you can identify potential hazards such as deck inserts, pipes, columns, openings, electrical cords or outlets, or any other objects protruding from the slab surface.
- This machine has no brain so you must use your own. There is no substitute for safety. The safety decals on the machine are to serve as a reminder for information you must already know before you begin using this machine. Take a moment to reread the safety decals each time you use the machine. If your machine is missing any decals, contact the factory for a replacement (EDCO 1-800-638-3326).

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Fax (301) 663-1607 • 1-800-447-3326



PARTS LIST MANUAL ELECTRIC POWER TROWELS

TABLE OF CONTENTS

<u>Section</u>	Page Number
Safety Messages and General Instructions	2
How To Order Replacement Parts	
Illustration 1: Handle Bar, Pitch Lever & Control Knob Grouping	4, 5
Illustration 2: Handle Adjustable Belly Bar Grouping	6
Illustration 3: On/Off Switch Grouping	7
Illustration 4: Frame, Transmission & Spider Grouping	8, 9
Illustration 5: Spider Assembly	10
Illustration 6: Bolt-On Blades & Adapter for 24" Trowel	
Illustration 7: Bolt-On Blades & Adapter for 30" Trowel	
Illustration 8: Bolt-On Blades & Adapter for 36" Trowel	
Illustration 9: Bolt-On Blades & Adapter for 46" Trowel	
Illustration 10: Optional Quick Change Blades & Adapters	
Illustration 11: Optional 36" Float Pan	
Illustration 12: Lift Handle Grouping	
Illustration 13: Motor Grouping for Baldor 1.5HP 1PH 60HZ	
Illustration 14: Motor Grouping for Leeson 2HP 1PH 60HZ	
Blank Page	
Illustration 15: Wiring Diagram	
Illustration 16: Wiring Diagram for Baldor 1.5 HP Motor	
Illustration 17: Wiring Diagram for Leeson 2 HP Motor	
Illustration 18: Optional "Tote-A-Trowel"	
Notes	
Limited Equipment Warranty of Sale - Terms & Conditions	28 (Back Page)

HOW TO ORDER REPLACEMENT PARTS

- ☐ To insure product safety and reliability, always use genuine EDCO replacement parts when making repairs to the equipment.
- □ When calling for parts, specify the MODEL and SERIAL number of the machine, which can be found on the NAME PLATE. Keep that information in the space provided. In addition to this information, give part number, description, and quantity as listed on the parts list to your parts representative.
- Please note: Due to improvements and changes in the equipment, the illustrations shown may be different than the actual machine.

FILL IN INFORMATION BELOW


Model #	 	

SKU#	



Date of Purchase __

ILLUSTRATION 1: HANDLE BAR, PITCH LEVER & CONTROL KNOB GROUPING



100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326


Fax (301) 663-1607 • 1-800-447-3326



	HANDL	PARTS LISTING - ILLUSTRATION 1 : LE BAR, PITCH LEVER & CONTROL KNOB GROUPING	
ITEM#	PART #	DESCRIPTION	QTY.
1	3661	DECAL, BLADE ANGLE - FLAT/TILT	1
2	49014	KNOB, CONTROL W/ 1/2-13 X 6-3/4"ROD	1
3	3642	BEARING, THRUST BALL 1/2	1
4	36078	HANDLE TOP INSERT	1
5	11639	SCREW, SKT. HD. CAP 5/16-18 X 5/8	1
6	36080	LINKAGE	1
7	11728	PIN, ROLL 3/8 X 1-3/4	1
8	36082	CABLE, CONTROL 3/16 X 51"L	1
	4610	CABLE, THIMBLE 3/16"	1
	3618	SLEEVE, NICOPRESS DOUBLE 3/16"	2
9	14082	PULLEY BEARING 1-1/4DIA. X 1/4BORE	2
10	10884	SCREW, SKT. BUTTON HD. 1/4-20 X 3/4	1
11	36081	LEVER, PITCH	1
12	14023	KNOB, BALL 1-3/8 W/ 1/2-13THD, BLK.	1
13	10001	SCREW, CAP 1/4-20 X 2-1/2	1
14	10602	WASHER, FLAT 1/4 SAE	2
15	10150	NUT, HEX NYLON LOCK 1/4-20	1
16	36070E	HANDLE BAR	1
17	10393	SCREW, CAP 3/8-24 X 2-1/2	1
18	10025	WASHER, FLAT 3/8 SAE	2
19	10058	NUT, LOCK 3/8-24 W/ NYLON PATCH	1
20	3621	PULLEY BEARING 1-3/4DIA. X 3/8BORE	1
21	36077	ROLLER GUIDE	1
22	10021	SCREW, CAP 3/8-24 X 1	4
23	10025	WASHER, FLAT 3/8 SAE	4
24	10004	NUT, LOCK 3/8-24	4



ILLUSTRATION 2: ADJUSTABLE HANDLE BELLY BAR GROUPING




ITENA //	DADT //	DECODIRTION	OTV
ITEM #	PART #	DESCRIPTION	QTY.
1	36071E	HANDLE BELLY BAR, ADJUSTABLE	1
2	36083	PADDING, BELLY BAR	1
3	10608	GRIP, HAND 1" MODEL AT	2
4	81001	SCREW, CAP 1/2-13 X 4	1
5	10312	WASHER, FLAT 1/2 SAE	2
6	10155	NUT, HEX NYLON LOCK 1/2-13	1
7	36063	KNOB, FLUTED 1/2-13 X 2-1/2"DIA.	2
8	10340	BOLT, TAP 1/2-13 X 3 (FULL THREAD)	2
9	36070E	HANDLE BAR (REF. TO ILLUS. 1, ITEM 16)	1

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Fax (301) 663-1607 • 1-800-447-3326




ILLUSTRATION 3: ON/OFF SWITCH GROUPING



ITEM#	PART#	DESCRIPTION	QTY.
1	36094	SWITCH, ON/OFF PUSH-BUTTON	1
2	36135	CORD WIRE 16/2 X 60"L (SWITCH TO CONN.)	1
3	11690	CLAMP, LOOM, 3/8"	1
4	3699	LEVER 3-3/4"	1
5	10314	SCREW, CAP 1/4-20 X 1-3/4	1
6	10015	NUT, LOCK 1/4-20	1
7		MODIFIED GRIP (REF. TO ILLUS. 2, ITEM 3)	1
8	36136	TUBING, HEAT SHRINK, TROWEL GRIP	1



ILLUSTRATION 4: FRAME, TRANSMISSION & SPIDER GROUPING




Printed in USA ©2010 JWA Page 8 100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326



			-PL-0310
		PARTS LISTING - ILLUSTRATION 4:	
ITENA (FRAME, TRANSMISSION & SPIDER GROUPING	OTV
ITEM#	PART #	DESCRIPTION	QTY.
1	00005	FRAME & GUARD RING	1
	36065	24" TROWEL	
	36066	30" TROWEL	
	36067 36068	36" TROWEL 46" TROWEL	
2	11729		4
		BOLT, TAP 3/8-24 X 1-3/4 FULL THD.	4
3	10025	WASHER, FLAT 3/8 SAE	8
4	10004	NUT, LOCK 3/8-24	4
5	36069	MOUNT, TRANSMISSION	1
6	10055	SCREW, CAP 3/8-16 X 1	6
7	10025	WASHER, FLAT 3/8 SAE	6
8		TRANSMISSION	1
	3664	20:1 RATIO - STANDARD SPEED (130 RPM MODELS)	
	3664-RS	40:1 RATIO - REDUCED SPEED (65 RPM MODELS)	
9	3609	BEARING, THRUST BALL 1-1/2"ID X 2-19/32"OD X 5/8"THK	1
10		PLATE, PITCH ADJUSTMENT	1
	3626	24, 30, & 36" TROWELS	
	4603	46" TROWELS	
11		SCREW, CAP	4
	10021	SCREW, CAP 3/8-24 X 1 (24, 30, & 36" TROWELS)	
	10322	SCREW, CAP 1/2-20 X 2 (46" TROWELS, ON INSIDE)	
12	0005	ROD END, MALE	4
	3605	3/8-24 (24, 30, & 36" TROWELS, AS SHOWN)	
10	4805	1/2-20 (46" TROWELS, MOUNTED ON OUTSIDE)	
13	10001	NUT, LOCK	40
	10004 10205	3/8-24 (24, 30, & 36" TROWELS)	12
1.1	10205	1/2-20 (46" TROWELS)	16
14	10025	WASHER, FLAT	8
	10025 10312	3/8 SAE (24, 30, & 36" TROWELS) 1/2 SAE (46" TROWELS)	
15	10312	SPIDER ASSEMBLY (REFER TO ILLUS. 5)	1
10	36084	24" TROWEL (8-1/2" ARMS)	'
	36085	30" TROWEL (12" ARMS)	
	36086	36" TROWEL (12" ARMS)	
	36087	46" TROWEL (15-1/4" ARMS)	
	36093	46" TROWEL (17-1/4"ARMS)	
16	3625	FORK	1
17	10816	SCREW, CAP 3/8-24 X 1-1/2	1
18	10030	SCREW, CAP 3/8-24 X 2	1
19	10004	NUT, LOCK 3/8-24	2
		1 - ,	



ILLUSTRATION 5: SPIDER ASSEMBLY




ITEM#	PART #	DESCRIPTION	QTY.
1	3637	HUB, 4 BLADE TROWEL	1
2	10052	SCREW, SET 5/16-18 X 3/8	8
3		ARM, BLADE	4
	2402	8-1/2" ARM, 24" TROWEL ,BOLT-ON BLADES	
	3666	12" ARM, 30" TROWEL, BOLT-ON OR QUICK-CHANGE	
	36007	13" ARM, 36" TROWEL, BOLT-ON OR QUICK-CHANGE	
	4618	15-1/4" ARM, 46" TROWEL, BOLT-ON BLADES	
	4606	17-1/4" ARM, 46" TROWEL, QUICK-CHANGE BLADES	
4		SHAFT, BLADE ARM	4
	3635	9-11/16"L SHAFT (24", 30", & 36" TROWEL)	
	4604	13-15/16"L SHAFT (46" TROWEL)	
5	3629	SPACER, ALUM. 1.25 X 1.017 X .090	8
6	10906	RETAINING RING, EXT. 1"	4
7	10808	FITTING, GREASE 1/4-28 STRAIGHT	4

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA

Printed in USA ©2010 JWA Page 10 Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326




ILLUSTRATION 6: BOLT-ON BLADES & ADAPTER FOR 24" TROWEL



ITEM#	PART#	DESCRIPTION	QTY.
1		BLADE	4
	40470	C-4 COMBINATION TROWEL BLADE 8 X 8 (SHOWN)	
	40480	F-4 FINISH TROWEL BLADE 6 X 8	
	40490	M-4 FLOAT TROWEL BLADE 9 X 8	
2	2406	BAR, BLADE MOUNTING 5/8"SQ. X 6"	4
3	11639	SCREW, SKT. HD. CAP 5/16-18 X 5/8	16
4	10801	WASHER, LOCK 5/16	16

ILLUSTRATION 7: BOLT-ON BLADES & ADAPTER FOR 30" TROWEL



ITEM#	PART#	DESCRIPTION	QTY.
1	40270-C	C-2C COMBINATION TROWEL BLADE 8 X 10-1/2	4
2	40280-C	F-2C FINISH TROWEL BLADE 6 X 10-1/2	4
3	3639	ADAPTER BAR 3/8" X 5/8" X 8-1/4"	4
4	11639	SCREW, SKT. HD. CAP 5/16-18 X 5/8	8
5	10606	SCREW, HEX HD. CAP 5/16-18 X 1-1/4	8
6	10801	WASHER, LOCK 5/16	20


Printed in USA ©2010 JWA

Page 12

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326




ILLUSTRATION 8: BOLT-ON BLADES & ADAPTER FOR 36" TROWEL



ITEM#	PART#	DESCRIPTION	QTY.
1	40040-C	C-1C COMBINATION TROWEL BLADE 8 X 14	4
2	40050-C	F-1C FINISH TROWEL BLADE 6 X 14	4
3	40060-CE	M-1CE FLOAT TROWEL BLADE 10 X 14 (SLIPS OVER FINISH BLADE)	4
4	36016	ADAPTER BAR 5/8"SQ. X 10-1/4"	4
5	11639	SCREW, SKT. HD. CAP 5/16-18 X 5/8	8
6	10606	SCREW, HEX HD. CAP 5/16-18 X 1-1/4	12
7	10801	WASHER, LOCK 5/16	20



ILLUSTRATION 9: BOLT-ON BLADES & ADAPTER FOR 46" TROWEL



ITEM#	PART #	DESCRIPTION	QTY.
1	40070-C	C-3C COMBINATION TROWEL BLADE 8 X 18	4
2	40080-C	F-3C FINISH TROWEL BLADE 6 X 18	4
3	40090-C	M-3C FLOAT TROWEL BLADE 10 X 18	4
		(SLIPS OVER FINISH BLADE)	
4	4619	ADAPTER BAR 5/8'SQ. X 12"	4
5	11639	SCREW, SKT. HD. CAP 5/16-18 X 5/8	12
6	10606	SCREW, HEX HD. CAP 5/16-18 X 1-1/4	8
7	10801	WASHER, LOCK 5/16	20


100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Printed in USA ©2010 JWA Page 14

Fax (301) 663-1607 • 1-800-447-3326 Website: www.edcoinc.com Email: sales@edcoinc.com




ILLUSTRATION 10: OPTIONAL QUICK CHANGE BLADES & ADAPTERS FOR 30", 36", & 46" TROWELS



ITEM#	PART#	DESCRIPTION	QTY.
1		COMBINATION BLADE (SHOWN)	4
	40270	C-2, 8" x 11"	
	40040	C-1, 8" x 14"	
	40070	C-3, 8" x 18"	
1		FLOAT BLADE	4
	40290	M-2, 9" x 11"	
	40060	M-1, 9" x 14"	
	40090	M-3, 9" x 18"	
1		FINISH BLADE	4
	40280	F-2, 6" x 11"	
	40050	F-1, 6" x 14"	
	40080	F-3, 6" x 18"	
2		ADAPTER COMPLETE (INCLUDES SPRINGS, ITEM 3)	4
	40197	"A", 30" & 36" TROWEL, 10-1/16"L (SHOWN)	
	40237	"B", 46" TROWEL, 14-3/16"L	
3		SPRING, EXTENSION	8
	3636	6"L ("A" ADAPTER)	
	4605	11-1/2"L ("B" ADAPTER)	
4	10053	SCREW, CAP 5/16-18 X 3/4	8/12
5	10213	WASHER, FLAT 5/16 SAE	8/12
6	10807	NUT, LOCK 5/16-18	8/12



ILLUSTRATION 11: OPTIONAL 36" FLOAT PAN




PART # 40710 WFP-36 PRO FLOAT PAN MILD DISH

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Fax (301) 663-1607 • 1-800-447-3326




ILLUSTRATION 12: LIFT HANDLE GROUPING



ITEM#	PART#	DESCRIPTION	QTY.
1	36091	HANDLE, LIFT	1
2	36092	HOLDER, LIFT HANDLE	1
3	10055	SCREW, CAP 3/8-16 X 1	2
4	10811	WASHER, LOCK 3/8	2
5	10025	WASHER, FLAT 3/8 SAE	2

ILLUSTRATION 13: MOTOR GROUPING FOR BALDOR 1.5HP 1PH 60HZ




Printed in USA ©2010 JWA Page 18 100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326



1 16061 MOTOR, BALDOR 1.5HP-1P 60HZ 3450RPM 115/230V 2 KEY 3/16SQ. X 1-3/8 (INCLUDED W/ MOTOR)	1 1
	1
	'
3 65243 COVER PLATE, SWITCH HOLE	1
4 10128 RIVET, BLIND 1/8 X .250L X .262HD	2
5 STARTER 16483 11-M1-BRF-R30-23-12060 (115 VOLT) 16484 11-M1-BRF-R30-15-23060 (230 VOLT)	1
6 10790 CONDUIT LOCK NUT 1/2 NP	3
7 41130 STRAIN RELIEF 1/2NPT X .550650"	2
8 16190 STRAIN RELIEF 1/2NPT X .250350"	1
9 CORD WIRE 12/3 (MOTOR TO STARTER, INCL. W/ MOTOR)	1
10 36137 CORD WIRE12/3 X 62"LOA, POWER (STARTER TO T.L. CONNE	CTOR) 1
11 40042 PLUG, LOCKING 20A/125V L5-20P	1
12 40041 CONNECTOR, LOCKING 20A/125V L5-20C	1
13 10982 TIE, CABLE, BLACK NYLON 11-1/4"	4
14 36138 CORD WIRE 16/2 X 15"LOA (STARTER TO CONNECTOR)	1
15 36131 CONNECTOR PLUG, SEALED 246-4402 36132 CONNECTOR RECEPT., SEALED 246-4414 36133 CONTACT, PIN 246-4424 36134 CONTACT, SOCKET 246-4428	1 1 2 2
16 10362 SCREW, MACHINE 8-32 X 3/4	4
17 10462 NUT, KEPS 8-32	4
18 36139 LIFTING BAIL/MOTOR MOUNT	1
19 10819 BOLT, CARRIAGE 5/16-18 X 1 FULL THD.	4
20 10213 WASHER, FLAT 5/16 SAE	4
21 10801 WASHER, LOCK 5/16	4
22 10054 NUT 5/16-18	4
23 11729 BOLT, TAP 3/8-24 X 1-3/4 FULL THD.	4
24 10025 WASHER, FLAT 3/8 SAE	8
25 10014 NUT 3/8-24	4
26 10004 NUT, LOCK 3/8-24	4
27 36097 SHEAVE 4.45"OD X 1GR.A X 3/4"BORE	1
28 36013 SHEAVE 6"OD X 1GR.A X 3/4"BORE	1
29 36108 TRANS. INPUT KEY 3/16SQ X 1 (INCLUDED W/ TRANSMISSION	N) 1
30 10259 BELT A-29	1
31 36072 COVER, BELT, TROWEL	1
32 10819 BOLT, CARRIAGE 5/16-18 X 1 FULL THD.	3
33 10213 WASHER, FLAT 5/16 SAE	3
34 10801 WASHER, LOCK 5/16	3
35 10054 NUT 5/16-18	3



ILLUSTRATION 14: MOTOR GROUPING FOR LEESON 2HP 1PH 60HZ





PARTS LISTING - ILLUSTRATION 14:					
	MOTOR GROUPING FOR LEESON 2HP 1PH 60HZ				
ITEM #	PART #	DESCRIPTION	QTY.		
1	16073	MOTOR, LEESON 2HP-1PH-60HZ-3450RPM 115/230V	1		
2		KEY 3/16SQ. X 1-3/8 (INCLUDED W/ MOTOR)	1		
3	40400	STARTER	1		
	16483 16484	11-M1-BRF-R30-23-12060 (115 VOLT) 11-M1-BRF-R30-15-23060 (230 VOLT)			
4	10790	CONDUIT LOCK NUT 1/2 NP	4		
5	41130	STRAIN RELIEF 1/2NPT X .550650"	3		
6	16190	STRAIN RELIEF 1/2NPT X .250350"	1		
7	36140	CORD WIRE 12/3 X 30"LOA (MOTOR TO STARTER)	1		
8	36137	CORD WIRE 12/3 X 62"LOA (POWER CORD)	1		
9	40042	PLUG, LOCKING 20A/125V L5-20P	1		
10	40042	CONNECTOR, LOCKING 20A/125V L5-20C	1		
11	10982	TIE, CABLE, BLACK NYLON 11-1/4"	4		
12	36138	CORD WIRE 16/2 X 15"LOA (STARTER TO CONNECTOR)	1		
13	36131	CONNECTOR PLUG, SEALED 246-4402	1		
	36132	CONNECTOR RECEPT., SEALED 246-4414	1 1		
	36133	CONTACT, PIN 246-4424	2		
	36134	CONTACT, SOCKET 246-4428	2		
14	10362	SCREW, MACHINE 8-32 X 3/4	4		
15	10462	NUT, KEPS 8-32	4		
16	36139	LIFTING BAIL/MOTOR MOUNT	1		
17	10819	BOLT, CARRIAGE 5/16-18 X 1 FULL THD.	4		
18	10213	WASHER, FLAT 5/16 SAE	4		
19	10801	WASHER, LOCK 5/16	4		
20	10054	NUT 5/16-18	4		
21	11729	BOLT, TAP 3/8-24 X 1-3/4 FULL THD.	4		
22	10025	WASHER, FLAT 3/8 SAE	8		
23	10014	NUT 3/8-24	4		
24	10004	NUT, LOCK 3/8-24	4		
25	36096	SHEAVE 4.45"OD X 1GR.A X 5/8"BORE	1		
26	36013	SHEAVE 6"OD X 1GR.A X 3/4"BORE	1		
27	36108	TRANS. INPUT KEY 3/16SQ X 1 (INCLUDED W/ TRANS.)	1		
28	10259	BELT A-29	1		
29	36072	COVER, BELT, TROWEL	1		
30	10819	BOLT, CARRIAGE 5/16-18 X 1 FULL THD	3		
31	10213	WASHER, FLAT 5/16 SAE	3		
32	10801	WASHER, LOCK 5/16	3		
33	10054	NUT 5/16-18	3		



THIS PAGE IS LEFT BLANK INTENTIONALLY

Printed in USA ©2010 JWA

Page 22

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326



ILLUSTRATION 15: WIRING DIAGRAM







ILLUSTRATION 16: WIRING DIAGRAM FOR BALDOR 1.5 HP MOTOR

BALDOR SPEC. NO. 35V801R760G1

USE CONNECTIONS FOR CLOCK-WISE ROTATION (OPP.) SHOWN BELOW HIGH = 230 VOLT, LOW = 115 VOLT ON/OFF SWITCH IS REMOVED



REPLACEMENT PARTS:

ELEC. (START) CAPACITOR: PART # 40051 BALDOR EC1645A06 645-774MFD 125V OIL (RUN) CAPACITOR: PART # 16164 BALDOR OC3040F09SP 40MFD 370V THERMAL PROTECTOR: PART # 16163 RESET BUTTON, BALDOR TPCRT40CA

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA


Printed in USA ©2010 JWA Page 24 Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326



ILLUSTRATION 17: WIRING DIAGRAM FOR LEESON 2 HP MOTOR

LEESON CAT. NO. 113632.00

USE CONNECTIONS FOR CLOCK-WISE (C.W.) ROTATION SHOWN BELOW HIGH VOLT = 230, LOW VOLT = 115
L1 IS BLACK & L2 IS WHITE



REPLACEMENT PARTS:


START CAPACITOR: PART # 16525 LEESON 003025.19 780MFD 125V W/ RES.

RUN CAPACITOR: PART # 16183 LEESON 003014.13 65MFD 240V

THERMAL PROTECTOR: PART # 16526 RESET BUTTON BEJ46DA, LEESON 300063.02



ILLUSTRATION 18: OPTIONAL "TOTE-A-TROWEL"



ITEM#	PART#	DESCRIPTION	QTY.
1	81400	TAT-II "TOTE-A-TROWEL" TRANSPORTER (INCLUDES ITEMS 2 THRU 5)	1
2	81401	FRAME	1
3	79013	WHEEL, 8 X 2-1/2 X 3/4"BRG.POLY HUB	2
4	10009	WASHER, FLAT 3/4 SAE	2
5	10306	PIN, COTTER 3/16 X 1-1/2	2

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Fax (301) 663-1607 • 1-800-447-3326



NOTES

Record here any repairs or changes made to the Equipment



LIMITED EQUIPMENT WARRANTY OF SALE - TERMS & CONDITIONS

Equipment Development Company, Inc. herein referred to as EDCO (Seller) warrants that each new unit manufactured by EDCO to be free from defects in material and workmanship in normal use and service for a period of (1) one year (except for the cutter drum assembly on all model concrete/asphalt planes, in which case the warranty period shall be 90 days) from date of shipment to the original retail or equipment rental center owner.

Accessories or equipment furnished and installed on the product by EDCO but manufactured by others, including, but not limited to engines, motors, electrical components, transmissions etc., shall carry the accessory manufacturers own warranty.

EDCO will, at its option, repair or replace, at the EDCO factory or at a point designated by EDCO, any part which shall appear to the satisfaction of EDCO inspection to have been defective in material or workmanship.

EDCO reserves the right to modify, alter and improve any part or parts without incurring any obligation to replace any part or parts previously sold without such modified, altered or improved part or parts.

This warranty is in lieu of and excludes all other warranties, expressed, implied, statutory, or otherwise created under applicable law including, but not limited to the warranty of merchantability and the warranty of fitness for a particular purpose in no event shall seller or the manufacturer of the product be liable for special, incidental, or consequential damages, including loss of profits, whether or not caused by or resulting from the negligence of seller and/or the manufacturer of the product unless specifically provided herein. In addition, this warranty shall not apply to any products or portions there of which have been subjected to abuse, misuse, improper installation, maintenance, or operation, electrical failure or abnormal conditions and to products which have been tampered with, altered, modified, repaired, reworked by anyone not approved by seller or used in any manner inconsistent with the provisions of the above or any instructions or specifications provided with or for the product

FORCE MAJEURE

Seller's obligation hereunder are subject to, and Seller shall not be held responsible for, any delay or failure to make delivery of all or any part of the Product due to labor difficulties, fires, casualties, accidents, acts of the elements, acts of God, transportation difficulties, delays by a common carrier, inability to obtain Product, materials or components or qualified labor sufficient to timely perform part of or all of the obligations contained in these terms and conditions, governmental regulations or actions, strikes, damage to or destruction in whole or part of manufacturing plant, riots, terrorist attacks or incidents, civil commotions, warlike conditions, flood, tidal waves, typhoon, hurricane, earthquake, lightning, explosion or any other causes, contingencies or circumstances within or without the United States not subject to the Seller's control which prevent or hinder the manufacture or delivery of the Products or make the fulfillment of these terms and conditions impracticable. In the event of the occurrence of any of the foregoing, at the option of Seller, Seller shall be excused from the performance under these Terms and Conditions, or the performance of the Seller shall be correspondingly extended.

This document sets forth the terms and conditions pursuant to which the purchaser ("Purchaser") will purchase and Equipment Development Co.Inc. ("Seller")will sell the products, accessories, attachments (collectively the Products") ordered by the Purchaser. These terms and conditions shall govern and apply to the sale of Seller's Products to Purchaser, regardless of any terms and conditions appearing on any purchase order or other forms submitted by Purchaser to Seller, or the inconsistency of any terms therein and herein.

1. PRICE

All prices set forth on any purchase order or other document are F.O.B. Sellers facility or distribution point, as may be determined by Seller (F.O.B.Point). All prices are exclusive of any and all taxes, including, but not limited to, excise, sales, use, property or transportation taxes related to the sale or use of the Products, now or hereafter imposed, together with all penalties and expenses. Purchaser shall be responsible for collecting and/or paying any and all such taxes, whether or not they are stated in any invoice for the Products. Unless otherwise specified herein, all prices are exclusive of inland transportation, freight, insurance and other costs and expenses relating to the shipment of the Products from the F.O.B. point to Purchaser's facility. Any prepayment by Seller of freight insurance and other costs shall be for the account of Purchaser and shall be repaid to Seller.

2. PAYMENT TERMS

Payment terms are as follows. 2% 10 days (to approved and qualified accounts). Net 30 days. This is a cash discount for invoices paid within 10 days after the invoice date, regardless of date of receipt of shipment. This is not a trade discount and will not be granted to accounts that do not adhere to stated terms.

*All past due accounts are subject to a late payment fee of 1.5% per month or a maximum allowed by law if different, along with the expenses incidental to collection including reasonable attorney's fees and costs.

*Seller reserves the right to hold shipments against past due accounts.

*Seller reserves the right to alter payment terms.

3. FREIGHT TERMS

All shipments will be made F.O.B. shipping point as designated in these Terms and Conditions, and title shall pass at the F.O.B. point. Delivery to the initial common carrier shall constitute delivery to the Purchaser. Any claims for loss or damage during shipment are to be filed with carrier by the Purchaser. Seller will not assume responsibility for the performance of the carrier.

Back orders will be shipped in the most practical fashion with charges consistent with our freight policy established with the original order. UPS, FED EX, MAIL or shipments by other couriers are subject to the same terms and conditions as outlined in paragraph #3"Freight Terms".

4. DELIVERY, DAMAGES, SHORTAGES

Seller shall use reasonable efforts to attempt to cause the Products to be delivered as provided for in these Terms & Conditions. Delivery to the initial common carrier shall constitute the delivery to the Purchaser. Sellers responsibility, in so far as transportation risks are concerned ceases upon the delivery of the Products in good condition to such carrier at the F.O.B. point and all the Products shall be shipped at the Purchaser's risk. Seller shall not be responsible or liable for any loss of income and/or profits, or incidental, special, consequential damages resulting from Seller's delayed performance in shipment and delivery.

5. RETURN OF DEFECTIVE PRODUCTS

Defective or failed material shall be held at the Purchaser's premises until authorization has been granted by Seller to return or dispose of Products. Products that are to be returned for final inspection must be returned Freight Prepaid in the most economical way. Credit will be issued for material found to be defective upon Seller's inspection based on prices at time of purchase.

6. PRODUCTS ORDERED IN ERROR

Products may be returned, provided that claim is made and Seller is notified within 7 days of receipt of Products, and the Products are in original buyer's possession not more than 30 days prior to return, subject to Seller's approval. If Products are accepted for return, they must be Freight Prepaid and buyer will be charged a minimum of 15% restocking charge, plus a charge back for outbound freight charges if the original order was shipped prepaid. Returns are not accepted for any Products that are specifically manufactured to meet the buyer's requirement of either specifications or quantity.

AGREEMENTS

These Terms and Conditions constitute the entire agreement between Seller and Purchaser as it relates to terms and conditions of sale, and supersedes any and all prior oral or written agreements, correspondence, quotations or understandings heretofore in force between the parties relating to the subject matter hereof. There are no agreements between Seller and Purchaser with respect to the Product herein except those specifically set forth in and made part of these terms and conditions. Any additional terms, conditions and/or prices are rejected by Seller.

These terms and conditions may be modified, cancelled or rescinded only by a written agreement of both parties executed by their duly authorized agents.

USE ONLY GENUINE EDCO PARTS & ACCESSORIES For your own safety, the safety of others and the life of your machine.

Equipment Development Company, Inc.

Printed in USA ©2010 JWA

Page 28

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326






PARTS LIST

MOTOR GROUPING FOR MODEL T464-5

STARTING SERIAL # 120210059





	PARTS LISTING - MOTOR GROUPING FOR MODEL T464-5				
ITEM#	PART#	DESCRIPTION	QTY.		
1	81026	MOTOR, BALDOR 5HP-1PH 60HZ 3450RPM	1		
	10101	REPLACEMENT PARTS:			
	16121 16164	CAPACITOR, START, BALDOR EC1161C06SP CAPACITOR, RUN, BALDOR #OC3040F09SP	2		
	16540	THERMAL PROT. (RESET BUTTON) TPBRT25DB			
2		KEY 1/4SQ. X 1-3/4 (INCLUDED W/ MOTOR)	1		
3	16454	STARTER ACI #128827 RESET ONLY 200/240V COIL 17.5-21.5A O/L	1		
		REPLACEMENT PARTS:			
	16617	STARTER CONTACTOR W/ COIL ACI SK18.310-230	1		
	16622 16637	STARTER AC COIL 200/240V-60HZ STARTER OVERLOAD RELAY 17.5-21.5 AMP	1 1		
4	41130	STRAIN RELIEF 1/2NPT X .550650"	2		
5	16190	STRAIN RELIEF 1/2NPT X .250350"	1		
6	36138	CORD WIRE 16/2 X 15"L (STARTER TO CONNECTOR)	1		
7	36131	CONNECTOR PLUG, SEALED 246-4402	1		
'	36132	CONNECTOR RECEPT., SEALED 246-4414	1		
	36133	CONTACT, PIN 246-4424	2		
	36134	CONTACT, SOCKET 246-4428	2		
8	36148	CORD WIRE 10/3 X 32"L (STARTER TO MOTOR)	1		
9	10740	CONDUIT LOCK NUT 3/4 NP	1		
10	16539	STRAIN RELIEF 90D X 3/4NPT .50625	1		
11	36149	CORD WIRE 10/3 X 70"L, POWER	1		
12	40037	PLUG, LOCKING 20A/250V L6-20P	1		
13	40000	CONNECTOR, LOCKING 20A/250V L6-20C	1		
14	10982	TIE, CABLE, BLACK NYLON 11-1/4"	4		
15	11732	SCREW, MACHINE 10-32 X 1-3/4 RPH	2		
	10384	SCREW, MACHINE 10-32 X 1 RHP	1		
16	10832	NUT, KEPS LOCK 10-32 ZINC	3		
17	36146	LIFTING BAIL/MOTOR MOUNT, 3&5 HP	1		
18	10802	BOLT, CARRIAGE 3/8-16 X 1 ZINC	4		
19	10025	WASHER, FLAT 3/8 SAE ZINC	4		
20	10811	WASHER, LOCK 3/8 ZINC	4		
21	10404	NUT, HEX 3/8-16 ZINC	4		
22	11729	BOLT, TAP 3/8-24 X 1-3/4(FULL THD.)	4		
23	10025	WASHER, FLAT 3/8 SAE ZINC	8		
24	11725	NUT, HEX JAM 3/8-24 ZINC	4		
25	10004	NUT, HEX LOCK 3/8-24 ZINC	4		
26	79023	SHEAVE 3"OD X 2GR.B X 1-1/8"BORE	1		
27	77058	SHEAVE 5"OD X 2GR.B X 3/4"BORE	1		
28	36108	TRANS. INPUT KEY 3/16SQ X 1 (INCLUDED W/ TRANSMISSION)	1		
29	10234	BELT 5L-290 (21/32" X 29")	2		
30	36072	COVER, BELT, TROWEL (4-3/16" WIDTH)	1		
31	10819	BOLT, CARRIAGE 5/16-18 X 1 FULL THD	3		
32	10213	WASHER, FLAT 5/16 SAE ZINC	3		
33	10801	WASHER, LOCK 5/16 ZINC	3		
34	10054	NUT, HEX 5/16-18 ZINC	3		

