REVISED STARTING SERIAL # 100610001

PARTS LIST MANUAL 48" CORE DRILL RIGS



SKU#	MODEL#	VACUUM PUMP	DRILL MOTOR	SPEED/RPM
97100EV	4820	INCLUDED	MILWAUKEE DYMO DRILL	2 SPEED
97100E	4820	NOT INCLUDED	20 AMP, 120 VOLT, 60 HZ	300/600



READ AND UNDERSTAND THE OPERATORS INSTRUCTION MANUAL THOROUGHLY BEFORE ATTEMPTING TO OPERATE THIS EQUIPMENT. Death or serious injury could occur if this machine is used improperly.



SAFETY MESSAGES



The safety instructions are proceeded by a graphic alert message of DANGER, WARNING, or CAUTION.



Indicates an imminent hazard which, if not avoided, will result in death or serious injury.



Indicates an imminent hazard which, if not avoided, can result in death or serious injury.



Indicates hazards which, if not avoided, could result in serious injury and or damage to the equipment.

GASOLINE '

Powered Equipment







 Do not operate gasoline powered equipment without adequate ventilation. Carbon monoxide is an invisible, odorless gas that can kill.

ELECTRICAL

Powered Equipment





<u>ELECTRICAL HAZARD</u> - Be sure equipment is properly grounded.
 Failure to comply could kill or result in serious injury.



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

GENERAL INSTRUCTIONS-





- You must read and understand the operators instruction manual and all other manuals associated with this machine. For your safety and the safety of others around you, it is extremely important to fully understand how to operate this machine in the way it was intended. Different model machines or older/newer versions of the same model may have different parts and controls that you need to understand. If instructions are not readable or available DO NOT USE this machine and contact the factory for a replacement Manual.
- You must be able to physically handle the bulk weight and power of this machine. If not properly controlled this machine can cause death or serious injury.
- Do not operate this machine in an impaired mental state. You must be able to exercise good judgement and reactions to maintain a safe working environment.
- This is a "one person" machine which means only one operator can
 be operating the machine at any one time. For the safety of others,
 maintain a safe operating distance to other personnel. Your work
 area should be defined and appropriately marked so bystanders and
 coworkers do not stand or walk near this machine and end up seriously
 injured by flying debris or exposing them to harmful noise or dust.
- This equipment is for Commercial use. Although this is a "one person" machine your work team should understand how to shut this machine off and quickly get medical help if an accident strikes the operator.
- Keep all guards in place during operation. The guards are to provide protection from inadvertent contact with dangerous moving parts, pinch points, or hot surfaces.
- Wear appropriate Personal Protective Equipment (PPE) including safety glasses, safety boots, work gloves, respiratory protection, hearing protection, and head protection. Do not wear loose clothing that can get tangled in moving parts. Failure to do so could result

- in dismemberment or death. Wear an approved respirator when removing hazardous materials or when grinding/cutting dry materials. Some dust particles such as concrete dust can contain silicate particles which can cause silicosis (a very serious lung disease). Contact NIOSH or OSHA for further details. When wet grinding/cutting, avoid contact with the concrete/asphalt slurry which can cause serious skin irritations.
- You must maintain this machine per the maintenance schedule in the
 operator manual. Remember before adjusting, servicing, or fueling this
 machine, disconnect the source of power to the machine by disconnecting the spark plug (Gas models), or by unplugging the electrical
 power cord (electric models) or air hose (Pneumatic models) AT THE
 MACHINE so you can assure yourself it remains unplugged while you
 are working on it. Do not modify this machine. Use only genuine EDCO
 parts and accessories. Repairs and service should be performed by
 approved EDCO dealers or authorized technicians.
- You should look carefully around the area before you begin work so you can identify potential hazards such as deck inserts, pipes, columns, openings, electrical cords or outlets, or any other objects protruding from the slab surface.
- This machine has no brain so you must use your own. There is no substitute for safety. The safety decals on the machine are to serve as a reminder for information you must already know before you begin using this machine. Take a moment to reread the safety decals each time you use the machine. If your machine is missing any decals, contact the factory for a replacement (EDCO 1-800-638-3326).

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Fax (301) 663-1607 • 1-800-447-3326



PARTS LIST MANUAL 48" CORE DRILL RIGS

TABLE OF CONTENTS

Section	Page Number
Safety Messages and General Instructions	2
How To Order Replacement Parts	3
Illustration 1: Base and Column Grouping	4, 5
Illustration 2: Vacuum Pump Assembly	6, 7
Illustration 3: Carriage Assembly	
Illustration 4: Drill Motor Grouping	10, 11
Illustration 5: Motor Mount Kit for 14" Drill Bit	12
Illustration 6: Motor Mount Kit for 16" Drill Bit	13
Illustration 7: Control Box Assembly	14
Illustration 8: Wiring Diagram for Control Box	15
Limited Equipment Warranty of Sale - Terms & Conditions	

HOW TO ORDER REPLACEMENT PARTS


- ☐ To insure product safety and reliability, always use genuine EDCO replacement parts when making repairs to the equipment.
- □ When calling for parts, specify the MODEL and SERIAL number of the machine, which can be found on the NAME PLATE. Keep that information in the space provided. In addition to this information, give part number, description, and quantity as listed on the parts list to your parts representative.
- Please note: Due to improvements and changes in the equipment, the illustrations shown may be different than the actual machine.

FILL IN INFORMATION BELOW

Date of Purchase
Model #
Serial #
SKU#



ILLUSTRATION 1: BASE AND COLUMN GROUPING



Printed in USA ©2010 JWA Page 4 100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326




	PARTS LISTING - ILLUSTRATION 1 : BASE AND COLUMN GROUPING				
ITEM#	PART#	DESCRIPTION	QTY.		
1	97003	VACUUM BASE, DRILL RIG	1		
2	97017	SCREW, SET 1/2-13 X 3 SQ. HD	4		
3	97020	SCREW, CAP 3/4-10 X 2	2		
4	10489	WASHER, LOCK 3/4	2		
5	97021	WASHER, FLAT 3/4 USS	2		
6	97044	MAST, 48" FOR LARGE DRILL RIG (COLUMN)	1		
7	97050	CEILING JACK, DRILL RIG	1		
8	97054K	WHEEL BASE ASSEMBLY (INCLUDES ITEMS 9 THRU 12)	1		
9	97054	WHEEL BASE PLATE	1		
10	80028	WHEEL 6 X 2 X 3/4"BRG.	2		
11	10009	WASHER, FLAT 3/4 SAE	4		
12	10306	PIN, COTTER 3/16 X 1-1/2	4		
13	10914	SCREW, CAP 1/2-13 X 1	1		
14	10045	WASHER, LOCK 1/2	1		
15	10312	WASHER, FLAT 1/2 SAE	1		

ILLUSTRATION 2: VACUUM PUMP ASSEMBLY

PART # 97043

NOTE: THE VACUUM PUMP IS NOT INCLUDED ON ALL MODELS



Printed in USA ©2010 JWA

Page 6

Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326




NOTE: THE VACUUM PUMP IS NOT INCLUDED ON ALL MODELS

	PARTS LISTING - ILLUSTRATION 2 : VACUUM PUMP ASSEMBLY			
ITEM#	PART#	DESCRIPTION	QTY.	
1-20	97043	VACUUM PUMP ASSEMBLY (INCLUDES ITEMS 1 THRU 20)	1	
1	97027	COMPRESSOR, 115V, 4.2A, 60HZ, 60PSI	1	
2	10799	BARB ELBOW 90, 3/8HOSE X 1/4MPT	1	
3	97071	HOSE 5/16"ID X 7/16"OD X 6"L (CLEAR)	1	
4	97032	NIPPLE, CLOSE, 1/4"NPT (BRASS)	1	
5	97031	CROSS, 1/4" NPT (BRASS)	1	
6	97030	GAUGE, VACUUM	1	
7	97029	VALVE, SHUT OFF, 1/4"NPT, 150PSI	1	
8	97033	PIPE NIPPLE, 1/4NPT X 3"L (BRASS)	1	
9	97028	WATER SEPARATOR	1	
10	97034	BARB, 1/4HOSE X 1/4MPT (BRASS)	1	
11	97055	HOSE 1/4"ID X 3/8"OD X 9"L (CLEAR)	1	
12	10708	BARB, 1/4HOSE X 1/8MPT (BRASS)	1	
13	97008	ANCHOR SLOT	1	
14	97038	GASKET, ANCHOR SLOT	1	
15	97037	GASKET, BASE	1	
16	97046	MOUNT PLATE, VACUUM PUMP	1	
17	10830	SCREW, MACHINE10-32 X 1/2	4	
18	10914	SCREW, CAP 1/2-13 X 1	1	
19	10045	WASHER, LOCK 1/2	1	
20	10312	WASHER, FLAT 1/2 SAE	1	



ILLUSTRATION 3: CARRIAGE ASSEMBLY




Printed in USA ©2010 JWA Page 8 100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326 Fax (301) 663-1607 • 1-800-447-3326



	PARTS LISTING - ILLUSTRATION 3 : CARRIAGE ASSEMBLY			
ITEM#	PART#	DESCRIPTION	QTY.	
1-16	97004A	CARRIAGE ASSEMBLY LESS HANDLE (INCLUDES ITEMS 1 THRU 16)	1	
1	97004	CARRIAGE	1	
2	97005	CARRIAGE COVER	1	
3	97047	WEAR STRIP 2.5 X 8.625 (4 HOLES IN CORNERS)	2	
4	97048	WEAR STRIP 2.5 X 8.625 (4 HOLES IN CENTER)	1	
5	97049	WEAR STRIP 1.0 X 8.625 (2 HOLES IN CENTER)	2	
6	97016	SCREW, FLAT HD MACHINE 10-32 X 1/2 BRASS	16	
7	10162	SCREW, SET 1/4-20 X 1/2"	8	
8	10031	SCREW, CAP 1/4-20 X 1	8	
9	10038	WASHER, LOCK 1/4	8	
10	10602	WASHER, FLAT 1/4 SAE	8	
11	97025	HANDLE, ALUMINUM 1/2-13 X 1 1/2	1	
12	97010	PINION GEAR	1	
13	97023	SPACER, BRASS 1 1/4 OD X 1"ID X 3/4	1	
14	97024	SPACER, BRASS 3/4OD X 1/2"ID X 3/8	1	
15	10312	WASHER, FLAT 1/2 SAE	2	
16	97014	RETAINING RING, EXT. 1/2"	1	
17	97052	HANDLE YOKE	1	
18	97026	SCREW, SKT.SHOULDER 5/8 X 1, 1/2-13	1	
19	97045	HANDLE, 10"	4	

ILLUSTRATION 4: DRILL MOTOR GROUPING




Page 10



	PARTS LISTING - ILLUSTRATION 4: DRILL MOTOR GROUPING				
ITEM#	PART#	DESCRIPTION	QTY.		
1	97001	DRILL MOTOR (INCLUDES ITEMS ITEMS 1 THRU 7) MILWAUKEE #4079, 20 AMP, 2 SPEED, SHEAR PIN	1		
*2	97065	WATER HOSE ADAPTER 42-04-0600	1		
*3	97064	SHUT OFF VALVE 45-80-0060	1		
*4	97062	PIN, SHEAR 44-60-0032	6		
*5	97068	RETAINING RING 34-60-1800	1		
*6	97059	COPPER WASHER 1-1/4 X 1-3/4 X 3/32	2		
7	97069	WRENCH 49-96-4700 (INCLUDED W/ DRILL MOTOR)	1		
8	97053	MOTOR MOUNT SPACER BLOCK	1		
9	97051	KEY 3/8"SQ X 4"L	2		
10	97015	SCREW, SKT. HD. CAP 1/4-20 X 1-1/4	4		
11	97012	SCREW, CAP 3/8-16 X 2-3/4	4		
12	10025	WASHER, FLAT 3/8 SAE	8		
13	10811	WASHER, LOCK 3/8	4		
14	10810	NUT, LOCK 3/8-16	4		
15	97072	ADAPTER 1 1/4-7 TO 5/8-11 (OPTIONAL FOR SMALL BITS)	1		
16	10073	WASHER, FLAT 5/8 SAE (OPTIONAL)	1		
* THESE ITEMS ARE INCLUDED WITH THE DRILL MOTOR IN A SEPARATE ACCESSORY BAG					

ILLUSTRATION 5: MOTOR MOUNT KIT FOR 14" DRILL BIT

OPTIONAL - PART # 97060K



ITEM#	PART#	DESCRIPTION	QTY.
1	97053	MOTOR MOUNT SPACER BLOCK	1
2	97051	KEY 3/8"SQ X 4"L	1
3	10868	SCREW, CAP 3/8-16 X 3-1/2	4


100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Printed in USA ©2010 JWA Page 12

Fax (301) 663-1607 • 1-800-447-3326 Website: www.edcoinc.com



ILLUSTRATION 6: MOTOR MOUNT KIT FOR 16" DRILL BIT




ITEM#	PART#	DESCRIPTION	QTY.
1	97053	MOTOR MOUNT SPACER BLOCK	2
2	97051	KEY 3/8"SQ X 4"L	2
3	10349	SCREW, CAP 3/8-16 X 4-1/2	4



Website: www.edcoinc.com

ILLUSTRATION 7: CONTROL BOX ASSEMBLY




ITEM#	PART#	DESCRIPTION	QTY.
1-11	97006A	CONTROL BOX COMPLETE (INCLUDES ITEMS 1 THRU 11)	1
1	97006	CONTROL BOX ONLY, DRILL RIG	1
2	97007	CONTROL BOX COVER, DRILL RIG	1
3	10834	SCREW, CAP 1/4-20 X 1/2	4
4	10038	WASHER, LOCK 1/4	4
5	16198	RECEPTACLE, LOCKING 20A-125V L520R	1
6	16199	RECEPTACLE, SINGLE 15A-125V 5258	1
7	16189	SWITCH, TOGGLE SPST 20/10A-125/250V	2
8	97009	AMMETER, 2 1/2" ROUND, 0-30AC AMPS	1
9	41130	STRAIN RELIEF 1/2NPT X .550650"	1
10	10790	CONDUIT LOCK NUT 1/2 NP	1
11	97057	PLUG, MOLDED, 12/3 CORD	1

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Fax (301) 663-1607 • 1-800-447-3326



ILLUSTRATION 8: WIRING DIAGRAM FOR CONTROL BOX



PARTS LISTING FOR WIRE AND TERMINALS REQUIRED				
PART#	DESCRIPTION	QTY.		
99017	WIRE, ELEC. 12 AWG BLACK STRANDED	36" TOTAL		
11715	TERM., FEM. PUSH-ON 12-10GA.	4		
10967	TERM., FLANGED SPADE #10 12-10GA.	4		
10968	TERM., RING 5/16 16-14GA. INSULATED	2		
10966	CONNECTOR, WIRE NUT (YELLOW)	1		



LIMITED EQUIPMENT WARRANTY OF SALE - TERMS & CONDITIONS

Equipment Development Company, Inc. herein referred to as EDCO (Seller) warrants that each new unit manufactured by EDCO to be free from defects in material and workmanship in normal use and service for a period of (1) one year (except for the cutter drum assembly on all model concrete/asphalt planes, in which case the warranty period shall be 90 days) from date of shipment to the original retail or equipment rental center owner.

Accessories or equipment furnished and installed on the product by EDCO but manufactured by others, including, but not limited to engines, motors, electrical components, transmissions etc., shall carry the accessory manufacturers own warranty.

EDCO will, at its option, repair or replace, at the EDCO factory or at a point designated by EDCO, any part which shall appear to the satisfaction of EDCO inspection to have been defective in material or workmanship.

EDCO reserves the right to modify, alter and improve any part or parts without incurring any obligation to replace any part or parts previously sold without such modified, altered or improved part or parts.

This warranty is in lieu of and excludes all other warranties, expressed, implied, statutory, or otherwise created under applicable law including, but not limited to the warranty of merchantability and the warranty of fitness for a particular purpose in no event shall seller or the manufacturer of the product be liable for special, incidental, or consequential damages, including loss of profits, whether or not caused by or resulting from the negligence of seller and/or the manufacturer of the product unless specifically provided herein. In addition, this warranty shall not apply to any products or portions there of which have been subjected to abuse, misuse, improper installation, maintenance, or operation, electrical failure or abnormal conditions and to products which have been tampered with, altered, modified, repaired, reworked by anyone not approved by seller or used in any manner inconsistent with the provisions of the above or any instructions or specifications provided with or for the product

FORCE MAJEURE

Seller's obligation hereunder are subject to, and Seller shall not be held responsible for, any delay or failure to make delivery of all or any part of the Product due to labor difficulties, fires, casualties, accidents, acts of the elements, acts of God, transportation difficulties, delays by a common carrier, inability to obtain Product, materials or components or qualified labor sufficient to timely perform part of or all of the obligations contained in these terms and conditions, governmental regulations or actions, strikes, damage to or destruction in whole or part of manufacturing plant, riots, terrorist attacks or incidents, civil commotions, warlike conditions, flood, tidal waves, typhoon, hurricane, earthquake, lightning, explosion or any other causes, contingencies or circumstances within or without the United States not subject to the Seller's control which prevent or hinder the manufacture or delivery of the Products or make the fulfillment of these terms and conditions impracticable. In the event of the occurrence of any of the foregoing, at the option of Seller, Seller shall be excused from the performance under these Terms and Conditions, or the performance of the Seller shall be correspondingly extended.

This document sets forth the terms and conditions pursuant to which the purchaser ("Purchaser") will purchase and Equipment Development Co.Inc. ("Seller")will sell the products, accessories, attachments (collectively the Products") ordered by the Purchaser. These terms and conditions shall govern and apply to the sale of Seller's Products to Purchaser, regardless of any terms and conditions appearing on any purchase order or other forms submitted by Purchaser to Seller, or the inconsistency of any terms therein and herein.

1. PRICE

All prices set forth on any purchase order or other document are F.O.B. Sellers facility or distribution point, as may be determined by Seller (F.O.B.Point). All prices are exclusive of any and all taxes, including, but not limited to, excise, sales, use, property or transportation taxes related to the sale or use of the Products, now or hereafter imposed, together with all penalties and expenses. Purchaser shall be responsible for collecting and/or paying any and all such taxes, whether or not they are stated in any invoice for the Products. Unless otherwise specified herein, all prices are exclusive of inland transportation, freight, insurance and other costs and expenses relating to the shipment of the Products from the F.O.B. point to Purchaser's facility. Any prepayment by Seller of freight insurance and other costs shall be for the account of Purchaser and shall be repaid to Seller.

2. PAYMENT TERMS

Payment terms are as follows. 2% 10 days (to approved and qualified accounts). Net 30 days. This is a cash discount for invoices paid within 10 days after the invoice date, regardless of date of receipt of shipment. This is not a trade discount and will not be granted to accounts that do not adhere to stated terms.

*All past due accounts are subject to a late payment fee of 1.5% per month or a maximum allowed by law if different, along with the expenses incidental to collection including reasonable attorney's fees and costs.

*Seller reserves the right to hold shipments against past due accounts.

*Seller reserves the right to alter payment terms.

3. FREIGHT TERMS

All shipments will be made F.O.B. shipping point as designated in these Terms and Conditions, and title shall pass at the F.O.B. point. Delivery to the initial common carrier shall constitute delivery to the Purchaser. Any claims for loss or damage during shipment are to be filed with carrier by the Purchaser. Seller will not assume responsibility for the performance of the carrier.

Back orders will be shipped in the most practical fashion with charges consistent with our freight policy established with the original order. UPS, FED EX, MAIL or shipments by other couriers are subject to the same terms and conditions as outlined in paragraph #3"Freight Terms".

4. DELIVERY, DAMAGES, SHORTAGES

Seller shall use reasonable efforts to attempt to cause the Products to be delivered as provided for in these Terms & Conditions. Delivery to the initial common carrier shall constitute the delivery to the Purchaser. Sellers responsibility, in so far as transportation risks are concerned ceases upon the delivery of the Products in good condition to such carrier at the F.O.B. point and all the Products shall be shipped at the Purchaser's risk. Seller shall not be responsible or liable for any loss of income and/or profits, or incidental, special, consequential damages resulting from Seller's delayed performance in shipment and delivery.

5. RETURN OF DEFECTIVE PRODUCTS

Defective or failed material shall be held at the Purchaser's premises until authorization has been granted by Seller to return or dispose of Products. Products that are to be returned for final inspection must be returned Freight Prepaid in the most economical way. Credit will be issued for material found to be defective upon Seller's inspection based on prices at time of purchase.

6. PRODUCTS ORDERED IN ERROR

Products may be returned, provided that claim is made and Seller is notified within 7 days of receipt of Products, and the Products are in original buyer's possession not more than 30 days prior to return, subject to Seller's approval. If Products are accepted for return, they must be Freight Prepaid and buyer will be charged a minimum of 15% restocking charge, plus a charge back for outbound freight charges if the original order was shipped prepaid. Returns are not accepted for any Products that are specifically manufactured to meet the buyer's requirement of either specifications or quantity.

AGREEMENTS

These Terms and Conditions constitute the entire agreement between Seller and Purchaser as it relates to terms and conditions of sale, and supersedes any and all prior oral or written agreements, correspondence, quotations or understandings heretofore in force between the parties relating to the subject matter hereof. There are no agreements between Seller and Purchaser with respect to the Product herein except those specifically set forth in and made part of these terms and conditions. Any additional terms, conditions and/or prices are rejected by Seller.

These terms and conditions may be modified, cancelled or rescinded only by a written agreement of both parties executed by their duly authorized agents.

USE ONLY GENUINE EDCO PARTS & ACCESSORIES For your own safety, the safety of others and the life of your machine.

Equipment Development Company, Inc.

Printed in USA ©2010 JWA

Page 16

100 Thomas Johnson Drive, Frederick, MD 21702-4600 USA Phone (301) 663-1600 • 1-800-638-3326

Fax (301) 663-1607 • 1-800-447-3326 Website: www.edcoinc.com Email: sales@edcoinc.com



